

## Table of Contents

**Room Positioning for Checking Oil Level in the HWH Slide Hydraulic Reservoir** ..... 3



# Room Positioning for Checking Oil Level in the HWH Slide Hydraulic Reservoir

If your coach is a 2000 year model or later and you likely have slide room extensions.

Checking the proper level of the reservoir depends on the type of extension mechanisms used in your particular year model coach. When adequately filled, the oil level of the reservoir will be approximately one inch below the top of the reservoir.

**FLUID** HWH Specialty Hydraulic Oil is recommended. In an emergency Dexron automatic transmission fluid can be used.

**NOTE** Dexron automatic transmission fluid contains red dye and can cause staining should a leak occur.

**DO NOT USE** brake fluid or hydraulic jack fluid. Use of these can damage seals.

All Foretravel systems are factory filled with Dexron III Automatic Transmission fluid.

It is important that all slide rooms are **positioned** per the below table **before** checking the hydraulic oil level. To check the oil supply, remove the breather cap from the top of the hydraulic oil reservoir. The oil level should be approximately one inch below the top of the reservoir when adequately filled.

Year	Location	Position
2007-xxxx (6435+)	Living Room	Extended
	Wardrobe	Extended
	Bed Slide	Retracted
	Generator Slide	Retracted
2003-2007 (thru 6434)	Living Room	Retracted
	Wardrobe	Extended
	Bed Slide	Retracted
	Generator Slide	Retracted
2002	Living Room	Extended
	Wardrobe	Extended
	Bed Slide	Retracted
2000-2001	Living Room	Retracted

From:

<https://wiki.foreforums.com/> - **Foretravel Wiki**

Permanent link:

[https://wiki.foreforums.com/technical:slide\\_out:checking\\_oil\\_level](https://wiki.foreforums.com/technical:slide_out:checking_oil_level)

Last update: **2021/03/10 12:31**

